

Citroën / Peugeot

RNEG / WIP NAV Navigation

User manual

Installation and initialization usually takes up to 3 minutes.

- Turn off the ignition;
- Remove your old card from the unit if any;
- Insert your new card;
- Turn on the ignition or start the engine;
- Wait for system initialization (usually it takes about 2 minutes)
- Switch to the navigation mode (press [NAV] button on your unit);
- Check the navigation settings. 2D map view is recommended.

After installation, use your navigation system as usual.

Known issues, also described at the item description page:

1. Due to low RAM memory size of RNEG MyWay / Wip Nav systems and large size of newly updated maps by 'HERE' '2017-2018, there can be black artefacts on the screen (only when you scroll and scale the map manually). Navigation mode works as usual. Switching the map to 2D view is recommended to avoid such behaviour.

2. For the same memory reason, no POI search and select available. However, POIs are displayed on the map normally;

You can update the firmware of your RNEG MyWay / WipNav unit to the latest version of the firmware. Optimized memory handling was used in the latest version of the firmware (R50b_R50.03 version). The latest version of the firmware is available for download at navi.uno tracker.

ATTENTION! Do not insert the car navigation memory card into any devices except your navigation unit (e.g. photo/video cameras, computer card readers, laptops and so on). This can cause data corruption and make the maps database unusable.

Have a nice journey!